

Operating instruction

SR 500



General information

Instructions for use for SR 500 should be read before use.

The SR 500 is a battery-powered fan that is included, together with the filter and approved human interface, in the Sundström respiratory protective system conforming to EN 12941/12942:1998 class TH3/TM3.

Available head tops for the SR 500 are listed in Instructions for use.

When selecting filters and head top, the following are some of the factors that must be taken into account:

- Types of pollutants
- Concentrations
- Work load
- Protection requirements in addition to respiratory protection

The risk analysis should be carried out by a person who has suitable training and experience in the area.

Unpacking the SR 500



Packing list:

- Fan unit SR 500
- Battery, STD
- Battery charger SR 513
- Belt SR 508
- Particle filter SR 510 P3 R, 2x
- Filter adapters, SR 511, 2x
- Pre-filters, SR 221, 10x
- Pre-filter holders, SR 512, 2x
- Flow meter SR 356
- User instructions
- Cleaning tissue SR 5226
- Plug kit

1. Assembling the fan unit, battery



1.1 On delivery, the battery is fitted to the fan with a protective tape over the battery terminals. Release the battery by placing the fan upside down.

Fold back the cover/lock on the battery a couple of centimetres and then push with the other thumb.



1.2 Remove the protective tape.



1.3 Connect the power supply lead to the battery charger. Connect the battery to the battery charger. Connect the power supply lead of the charger to the wall socket.

N.B. Mains voltage of 100-240V.

Charging takes place automatically in 3 steps

1. Orange LED
2. Yellow LED
3. Green LED



Push the battery back into the battery compartment. Check that the battery has been pushed in as far as it will go and that its lock is operative.

2. Assembly belt

2.1 Assemble the belt by pressing together the two halves of the buckle.



2.2 The belt should be mounted so that the belt is pointing upwards. Insert the three tongues of the belt half into the slot in the fan. Begin to insert the upper tongue and then turn the belt into the fan.



2.3 Press down the three lips locking the belt half.



2.4 Correctly mounted belt.



3. Particle filter



3.1 Check that the gaskets in the filter mounting of the fan unit are in place and are in good condition.



3.2 Snap the filter onto the filter adapter.



3.3 Do not press onto the centre of the filter – it might damage the filter paper.



3.4 Screw the adapter into the filter mounting so far that the adapter will be in contact with the gasket.

Then turn it about 1/8 turn further in order to ensure a good seal.

Particle filter

3.5 Fit one pre-filter into the filter holder.



3.6 The pre-filter should have slipped under the shoulders in the pre-filter holder.



3.7 Press the filter holder onto the particle filter.



3.8 Correctly mounted pre-filter holder with particle filter.



4. Combined filters, Gas filter + particle filter



4.1 Snap the particle filter onto the gas filter. The arrows on the particle filter must point towards the gas filter.



4.2 Do not press onto the centre of the filter it might damage the filter paper.



4.3 Check that the gaskets in the filter mounting of the fan unit are in place and are in good condition.

Combined filers, Gas filter + particle filter

4.4 Fit one pre-filter, SR 221 into the filter holder.



4.5 Screw the filter combination into the filter mounting so far that the filter will be in contact with the gasket. Then turn it about 1/8 turn further in order to ensure a good seal. Press the filter holder onto the particle filter.



4.6 Correctly mounted pre-filter holder.



The filters used must be of the same type, i.e. two SR 510 P3 or two SR 518 A2/SR 510 P3, etc. When filters are changed, both filters/combined filters must be changed at the same time.

5. Operation/Performance



5.1 Start the fan by pressing the control button.



5.2 After the button has been pressed, a programmed test will be run on the fan and the display will then light up, the audible signal will sound, and the vibrator will vibrate twice.



5.3 If the button is pressed again, the flow will increase to 240 l/min, and this is indicated by the large fan symbol lighting up. If the control button is pressed again, the fan flow rate will revert to 175 l/min and the small fan symbol will again light up.

Operation/Performance



5.4 The battery symbol on the display indicates the battery capacity.

1. Lights green: > 70 %
2. Flashing green: 50-70 %
3. Lights yellow: 20-50 %
4. Flashing red: < 20 %



5.5 When about 5% of the battery capacity is left, the fan will begin to initiate an alarm and the battery symbol will flash. The battery capacity is sufficient to allow the work to be concluded without undue haste. The work should then be interrupted and the wearer of the equipment should leave the site.



5.6 To switch off the fan, keep the control button depressed for about 2 seconds.

6. Performance check, minimum flow



6.1 Check that the fan is complete with filters, is correctly fitted, cleaned and undamaged.

Start the fan unit.

Connect the hose from the head top to the fan and turn it about 1/8 of a turn clockwise.



6.2 Turn the flow meter bag inside out so that the transparent measuring tube is on the outside.

Note. If the bag is turned with the measuring tube inwards, it can be used as a storage bag.



6.3 Place the head top in the flow meter bag and start the fan unit.

Grip the lower part of the bag in order to seal around the hose.

Grip around the measuring tube and hold the tube vertical.

The ball should now float level with or just over the 175 l/min marking.

If the minimum flow is not achieved, check that:

- The flow meter is vertical
- The ball moves freely
- The bag seals well around the hose.

7. Performance check, alarms

The equipment is designed to provide a warning if the air flow is obstructed, and this should be checked in conjunction with the flow. Check before the equipment is taken into use.

N.B. If the minimum flow is not achieved or if the alarm signals do not operate as intended, the fan must not be used.



7.1 Cause a flow stoppage by still holding tightly the joint between the hose and the flow meter bag and then blocking off the flow meter outlet.



7.2 The fan will now initiate an alarm by audible and visual signals and vibrations.



7.3 If the flow meter outlet is now unblocked and the air is allowed to flow freely, the alarm signals will cease within 10 – 15 seconds.

Switch off the fan and remove the head top from the flow meter bag.

8. Putting the equipment on

Before putting the equipment on, read carefully the user instructions for the head top.

After the filter has been fitted, a performance check has been carried out and the head top has been connected, the equipment can be put on.



8.1 Snap the two parts of the buckle together.

After the buckles have been connected, tighten the belt so that it is comfortable.



8.2 The fan should be firmly in contact with the wearer's back in order to ensure optimum comfort and ergonomic benefits.



8.3 Put the belt ends in the clips on each side of the belt.

9. To change the particle filters



9.1 Change particle filter by bending the pre-filter holder from the filter adapter.

Bear in mind that both filters must be changed at the same time.



9.3 Change pre-filter by press it in the middle and then remove it.



9.2 Grip the filter with one hand.

Place the thumb of the other hand on the underside of the adapter at the semi-circular gap. Then prise out the filter.

To change the gasfilters, combined filters



9.4 To change the gas filter: Unscrew the filter/combined filter. To change the gas filter, prise the particle filter off the gas filter.

Bear in mind that both filters/combined filters must be changed at the same time and must be of the same type and class.



9.5 As an alternative, the filter combination can be separated by means of the filter adapter.

10. Cleaning/Disinfection



10.1 The plug kit is used for cleaning or decontamination of the fan unit and prevents dirt and water from entering the fan housing.

Disconnect the breathing hose and the filters and install the plugs.



10.2 In the event of heavy fouling, a soft brush or sponge wetted with a solution of water and dishwashing detergent can be used.



10.3 An SR 5226 cleaning wipe should be used for daily cleaning.

Wipe the outside of the fan.

If necessary, spray the product with 70 % ethanol or isopropanol solution for disinfection.

Cleaning/Disinfection



10.4 Clean the pre-filter holders inside and out.



10.5 Wipe the filter adapter clean.
Check that the sealing ridge for the particle filter is undamaged.



10.6 Wipe the belt clean.

11. Maintenance schedule

	Before use	After use	Annually
Visual inspection	○	○	
Performance check	○		○
Cleaning		○	
Change of fan gaskets			○

The following schedule shows the recommended minimum maintenance procedures required in order to ensure that the equipment is always in functional condition.



11.1 The gasket has a groove all round and is fitted on a flange below the threads in the filter mounting.

Remove the old gasket.



11.2 Fit the new gasket onto the flange. Check that the gasket is in place all round.

Troubleshooting schedule

Fault	Reason	Action
The fan unit fails to start	Battery discharged	Recharge battery
	Fan-battery contact problems	Bend/adjust/clean the battery terminals. Check that there are two terminals. Check the contact rivets on the fan.
	Battery faulty	New battery, test another battery Measure the voltage which should be 13 – 17 V
	Charger faulty, fails to charge the battery.	Make a visual check and make sure that there is no dirt on the contacts to the charger or battery. A new battery charger.
	Fan motor/electronic fault	Send the fan unit for repair
Yellow battery symbol flashes	Battery discharged	Recharge the battery

Troubleshooting schedule

Fault	Reason	Action
Red triangle flashes on the display and the fan sounds and vibrates	Filters clogged	Change the pre-filters Change the particle filters
	Hose damaged	Check that the air flows freely through the hose and that the hose is in good condition
	Valves	Check that the exhalation valves with membranes are fitted to your head top.
Irregular air flow	Filter clogged Incorrect combination No filters mounted	Check that there are filters in the fan unit and that they are of the same type. i.e. SR 518 A2 + SR 510 P3 R

Operation instructions

SR 530

Hood



General information

Instructions for use for SR 530 should be read before use.

The SR 530 together with fan unit SR 500/SR 500 EX/SR 700 and approved filters are included in the Sundström fan-assisted respiratory protective device system conforming to EN 12941/EN 12942:1998 class TH3.

Combination of SR 530-SR 500 EX is specially designed for using in potentially explosive and fire hazardous environments. See user instructions or label on fan unit for classification.

SR 530 together with compressed air attachment SR 507 and breathing hose SR 358/SR 359/SR 360 are included in the Sundström compressed air-fed respiratory device system conforming to EN 14594:2005 class 3A/3B.

When selecting equipment for SR 530 some of the factors that should be considered are as follows:

- Type of pollutant
- Concentrations
- Work intensity
- Protection requirements in addition to respiratory protective advice.

Risk analysis should be carried by a person who has suitable training and experience in the area.

Unpacking



Packing list:

- Hood with breathing hose.
- User instructions
- Cleaning tissue

1. Assembly



1.1 Remove the protective film from the visor.



1.2 Check that the O-ring of the hose is in place.



1.3 Connect the hose to the fan unit and turn it clockwise about 1/8 of a turn.

2. Functional check before use

2.1 Turn the flow meter bag inside out and the flow meter appears.



2.2 Place the head-top in the flow meter and start the fan unit. Grip the bag to seal around the breathing hose. Grip the flow meter tube with the other hand, the tube will point upwards from the bag

Read the position of the ball in the tube. This should hover at a level with or slightly above the upper marking on the tube, (175 l/min).

If minimum flow is not achieved, check that

- the flow meter is held upright,
- the ball moves freely,
- the bag seals well around the hose.



3. Putting the hood on



3.1 Adjust the head harness by adjusting the length of the Velcro strap. This is important for ensuring a good fit.

Connect the hose, put the fan unit on and start it. See the user instructions for the SR 500.



3.2 Hold the hood upside down. Grip each side of the hood opening with one hand.



3.3 Pull the hood down so that the head harness fits firmly and comfortably around your head.

3.4 Adjust the neck size of the hood by means of the elastic neck strap.



3.5 Make sure that the breathing hose runs along your back and is not twisted.



4. To exchange the exhalation membrane



4.1 Snap off the valve cover. The cover must be changed at the same time as the membrane.



4.2 Slip off the membrane.



4.3 Press the new membrane onto the pin. Carefully check that the membrane is in contact with the valve seat all way round.



4.4 Press the valve cover into place. A clicking sound indicates that it is in place.

5. Change the sweatband



5.1 Pick away one end of the sweatband so that it is removed together with the tape Pull sweatband off.



5.2 Remove the protective paper



5.3 Fit the new sweatband. The forehead strap and the sweatband should be mounted edge to edge.

6. Cleaning

If necessary, spray the product with 70 % ethanol or isopropanol solution for disinfection.

N.B. Never use a solvent for cleaning.



6.1 Sundström cleaning tissues SR 5226 are recommended for daily care.



6.2 If the equipment is more heavily fouled, use a soft brush or sponge moistened with a solution of water and dishwashing detergent or the like. Rinse the equipment and leave it to dry.



6.3 Snap off the valve cover from the valve seat.



6.4 Slip of the membrane
Clean the exhalation membrane.



6.5 Clean the valve seat and check that the valve seat is ok.



6.6 Clean the valve cover on the inside and outside.

7. Maintenance schedule

The schedule represents the minimum requirements for maintenance routines in order to ensure that equipment will always be in functional condition.

	Before use	After use	Annually
Visual inspection	•	•	•
Functional check	•		•
Cleaning		•	•
Change of exhalation membrane			•